

Department of Electrical Engineering
University of Arkansas



ELEG 3124 SYSTEMS AND SIGNALS

Ch. 2 Continuous-Time Systems

Dr. Jingxian Wu
wuj@uark.edu

OUTLINE

- **Classifications of continuous-time system**
- **Linear time-invariant system (LTI)**
- **Properties of LTI system**
- **System described by differential equations**

CLASSIFICATIONS: SYSTEM DEFINITION

- **What is system?**


- A system is a process that transforms input signals into output signals
 - Accept an input
 - Process the input
 - Send an output (also called: the **response** of the system to input)
- System examples:
 - Radio: input: electrical signals from air, output: music
 - Robot: input: electrical control signals, output: motion or action

- **Continuous-time system**

- A system in which continuous-time input signals are transformed to continuous-time output signals

- **Discrete-time system**

- A system in which discrete-time input signals are transformed to discrete-time output signals.




CLASSIFICATIONS: SYSTEM DEFINITION

- **Classifications**
 - Linear v.s. non-linear
 - Time-invariant v.s. time-varying
 - Dynamic v.s. static (memory v.s. memoryless)
 - Causal v.s. non-causal
 - Invertible v.s. non-invertible
 - Stable v.s. non-stable

CLASSIFICATIONS: LINEAR AND NON-LINEAR

- **Linear system**

- Let $y_1(t)$ be the response of a system to an input $x_1(t)$
- Let $y_2(t)$ be the response of a system to an input $x_2(t)$
- The system is linear if the **superposition principle** is satisfied:
 - 1. the response to $x_1(t) + x_2(t)$ is $y_1(t) + y_2(t)$
 - 2. the response to $\alpha x_1(t)$ is $\alpha y_1(t)$



- **Non-linear system**

- If the superposition principle is not satisfied, then the system is a non-linear system

CLASSIFICATIONS: LINEAR AND NON-LINEAR

- **Example: check if the following systems are linear**

- System 1: $y(t) = \exp[x(t)]$

- System 2: charge a capacitor. Input: $i(t)$, output $v(t)$

$$v(t) = \frac{1}{C} \int_{-\infty}^t i(\tau) d\tau$$

- System 3: inductor. Input: $i(t)$, output $v(t)$

$$v(t) = L \frac{di(t)}{dt}$$

CLASSIFICATIONS: LINEAR AND NON-LINEAR

- **Example**

- System 4:
$$y(t) = \frac{1}{T} \int_{t-T}^t x(\tau) d\tau + B$$


- System 5:
$$y(t) = |x(t)|$$

- System 6:
$$y(t) = x^2(t)$$

CLASSIFICATIONS: LINEAR V.S. NON-LINEAR

- **Example:**


- Amplitude Modulation:
 - Is it linear?



CLASSIFICATIONS: TIME-VARYING V.S. TIME-INVARIANT

- **Time-invariant**

- A system is time-invariant if a time shift in the input signal causes **an identical time shift** in the output signal



- **Examples**

- $y(t) = \cos(x(t))$

- $y(t) = \int_0^t x(v) dv$


CLASSIFICATIONS: MEMORY V.S. MEMORYLESS

- **Memoryless system**

- If the **present value of the output** depends only on the **present value of input**, then the system is said to be memoryless (or instantaneous).

- Example: input $x(t)$: the current passing through a resistor
output $y(t)$: the voltage across the resistor

$$y(t) = Rx(t)$$



- The output value at time t depends only on input value at time t .

- **System with memory**

- If the present value of the output depends on not only present value of input, but also previous input values, then the system has memory.

- Example: capacitor, current: $x(t)$, output voltage: $y(t)$

$$y(t) = \frac{1}{C} \int_0^t x(\tau) d\tau$$

- the output value at t depends on all input values before t

CLASSIFICATIONS: MEMORY V.S. MEMORYLESS

- **Examples: determine if the systems has memory or not**

- $$y(t) = \sum_{i=0}^N a_i x(t - T_i)$$

- $$y(t) = \sin(2x^2(t) + \theta)x(t)$$

CLASSIFICATIONS: CAUSAL V.S. NON-CAUSAL

- **Causal system**

- A system is causal if the output $y(t_0)$ depends only on values of input for $t \leq t_0$
 - The output depends on only input from the past and present
- Example

$$y(t) = \frac{1}{C} \int_0^t x(\tau) d\tau$$

- **Non-causal system**

- A system is non-causal if the output depends on the input from the future (prediction).
- Examples:


$$y(t) = x(t + a) \quad a > 0 \qquad y(t) = \frac{1}{T} \int_{-T/2}^{T/2} x(\tau) d\tau$$

- The output value at t depends on the input value at $t + a$ (from future)
- All practical systems are causal.

CLASSIFICATION: INVERTIBILITY

- **Invertible**

- A system is invertible if
 - by observing the output, we can determine its input.



- Question: for a system, if two different inputs result in the same output, is this system invertible?

- **Example**

$$y(t) = 2x(t)$$

$$y(t) = \cos[x(t)]$$

- If two different inputs result in the same output, the system is non-invertible

CLASSIFICATION: STABILITY

- **Bounded signal**

- Definition: a signal $x(t)$ is said to be bounded if

$$|x(t)| < B < \infty \quad \forall t$$

- **Bounded-input bounded-output (BIBO) stable system**

- Definition: a system is BIBO stable if, for any bounded input $x(t)$, the response $y(t)$ is also bounded.

$$|x(t)| < B_1 < \infty \Rightarrow |y(t)| < B_2 < \infty \quad \forall t$$

- **Example: determine if the systems are BIBO stable**

$$y(t) = \exp[x(t)]$$

$$y(t) = \int_{-\infty}^t x(\tau) d\tau$$


OUTLINE

- Classifications of continuous-time system
- **Linear time-invariant system (LTI)**
- Properties of LTI system
- System described by differential equations

LTI: DEFINITION

- **Linear time-invariant (LTI) system**

- Definition: a system is said to be LTI if it's linear and time-invariant



- Linear

$$\text{Input: } x(t) = a_1x_1(t) + a_2x_2(t) + \cdots + a_Nx_N(t) = \sum_{i=1}^N a_i x_i(t)$$

$$\text{Output: } y(t) = a_1y_1(t) + a_2y_2(t) + \cdots + a_Ny_N(t) = \sum_{i=1}^N a_i y_i(t)$$

- Time-invariant


$$\text{Input: } x(t) = x_i(t - t_0)$$

$$\text{Output: } y(t) = y_i(t - t_0)$$

LTI: IMPULSE RESPONSE

- **Impulse response of LTI system**

- Def: the output (response) of a system when the input is a unit impulse function (delta function).
 - Usually denoted as $h(t)$



- **For system with an arbitrary input $x(t)$, we want to find out the output $y(t)$.**
 - Method 1: differential equations
 - Methods 2: convolution integral
 - Methods 3: Laplace transform, Fourier transform,


LTI: CONVOLUTION

• Derivation

- Any signal can be approximated by **the sum of a sequence of delta functions**

$$\int_{-\infty}^{+\infty} z(\tau) d\tau = \lim_{\Delta \rightarrow 0} \sum_{n=-\infty}^{+\infty} z(n\Delta) \Delta$$

$$x(t) = \int_{-\infty}^{+\infty} x(\tau) \delta(t - \tau) d\tau = \lim_{\Delta \rightarrow 0} \sum_{n=-\infty}^{+\infty} x(n\Delta) \delta(t - n\Delta) \Delta$$




LTI: CONVOLUTION


- **Derivation**

- Any signal can be approximated by **the sum of a sequence of delta functions**


$$x(t) = \int_{-\infty}^{+\infty} x(\tau)\delta(t-\tau)d\tau = \lim_{\Delta \rightarrow 0} \sum_{n=-\infty}^{+\infty} x(n\Delta)\delta(t-n\Delta)\Delta$$



- Time invariant




- Linear



LTI: CONVOLUTION

- Convolution




- **Definition:** the convolution of two signals $x(t)$ and $h(t)$ is defined as

$$y(t) = \int_{-\infty}^{+\infty} x(\tau)h(t-\tau)d\tau$$

- The operation of convolution is usually denoted with the symbol \otimes

$$y(t) = x(t) \otimes h(t) = \int_{-\infty}^{+\infty} x(\tau)h(t-\tau)d\tau$$



**For LTI system, if we know input $x(t)$ and impulse response $h(t)$,
Then the output is $x(t) \otimes h(t)$**

LTI: CONVOLUTION

- **Examples**


$$x(t) \otimes \delta(t)$$

$$x(t) \otimes \delta(t - t_0)$$

$$x(t) \otimes u(t)$$

LTI: CONVOLUTION

- **Examples**



LTI: CONVOLUTION

- **Example**

- Obtain the impulse response of a capacitor and use it to find the unit-step response by using convolution. Assume the input is the current, and the output is the voltage. Let $C = 1\text{F}$.

$$v(t) = \frac{1}{C} \int_{-\infty}^t i(\tau) d\tau$$

LTI: CONVOLUTION PROPERTIES

- **Commutativity**

$$x(t) \otimes y(t) = y(t) \otimes x(t)$$

– Proof:

$$x(t) \otimes y(t) = \int_{-\infty}^{+\infty} x(\tau) y(t - \tau) d\tau$$




LTI: CONVOLUTION PROPERTIES

- **Associativity**

$$x(t) \otimes h_1(t) \otimes h_2(t) = [x(t) \otimes h_1(t)] \otimes h_2(t) = x(t) \otimes [h_1(t) \otimes h_2(t)]$$

– proof




LTI: CONVOLUTION PROPERTIES

- Distributivity


$$x(t) \otimes [h_1(t) + h_2(t)] = [x(t) \otimes h_1(t)] + [x(t) \otimes h_2(t)]$$

– proof



LTI: CONVOLUTION PROPERTIES

- Examples



$$h_1(t) = \exp(-2t)u(t)$$

$$h_3(t) = \exp(-3t)u(t)$$

$$h(t) = ?$$



$$h_2(t) = 2\exp(-t)u(t)$$

$$h_4(t) = 4\delta(t)$$


LTI: GRAPHICAL CONVOLUTION

- Graphical interpretation of convolution


$$y(t) = \int_{-\infty}^{+\infty} x(\tau)h(t-\tau)d\tau$$



– 1. Reflection $g(\tau) = h(-\tau)$



– 2. Shift $g(\tau - t_0) = h(-(\tau - t_0)) = h(t_0 - \tau)$



– 3. Multiplication $x(\tau)h(t_0 - \tau)$

– 4. Integration $y(t_0) = \int_{-\infty}^{+\infty} x(\tau)h(t_0 - \tau)d\tau$

LTI: GRAPHICAL CONVOLUTION

- **Example**

$$y(t) = [2a \cdot p_{2a}(t)] \otimes [2a \cdot p_{2a}(t - a)]$$

OUTLINE

- Classifications of continuous-time system
- Linear time-invariant system (LTI)
- **Properties of LTI system**
- System described by differential equations

LTI PROPERTIES

- **Memoryless LTI system**

- Review: present output only depends on present input

$$y(t) = Kx(t)$$

- The impulse response of Memoryless LTI system is

$$h(t) = K\delta(t)$$

- **Causal LTI system**

- Review: output depends on only current input and past input.
- The impulse response of causal LTI system must satisfy:


$$h(t) = 0 \quad \text{for } t < 0$$

- Why?

LTI PROPERTIES

- **Invertible LTI Systems**

- Review: a system is invertible iff (if and only if) there is an inverse system that, when connected in cascade with the original system, yields an output equal to original system input



$$x(t) \otimes h(t) \otimes g(t) = x(t)$$

- For invertible LTI systems with IR (impulse response) $h(t)$, there exists inverse system $g(t)$ such that

$$g(t) \otimes h(t) = \delta(t)$$

- Example: find the inverse system of LTI system $h(t) = \delta(t - t_0)$

LTI PROPERTIES

- **BIBO Stable LTI state**

- Review: a system is BIBO stable iff every bounded input produces a bounded output.
- LTI system: an LTI system is BIBO stable iff

$$\int_{-\infty}^{+\infty} |h(t)| dt < \infty$$

- Proof:

LTI PROPERTIES

- **Examples**

- Determine: causal or non-causal, memory or memoryless, stable or unstable
- 1. $h_1(t) = t \exp(-2t)u(t) + \exp(3t)u(-t) + \delta(t-1)$
- 2. $h_2(t) = -3 \exp(2t)u(t)$
- 3. $h_3(t) = 5\delta(t+5)$

OUTLINE

- Classifications of continuous-time system
- Linear time-invariant system (LTI)
- Properties of LTI system
- **System described by differential equations**

DIFFERENTIAL EQUATIONS

- **LTI system can be represented by differential equations**

$$a_0 y(t) + a_1 y'(t) + \cdots + a_N y^{(N)}(t) = b_0 x(t) + b_1 x'(t) + \cdots + b_M x^{(M)}(t)$$

- Initial conditions:

$$\left. \frac{d^k y(t)}{dt^k} \right|_{t=0} \quad k = 0, \dots, N-1$$

- Notation: n-th derivative:

$$y^{(n)}(t) = \frac{d^n y(t)}{dt^n}$$

DIFFERENTIAL EQUATION

- **Example:**

- Consider a circuit with a resistor $R = 1$ Ohm and an inductor $L = 1$ H, with a voltage source $v(t) = Bu(t)$, and I_o is the initial current in the inductor. The output of the system is the current across the inductor.
 - Represent the system with a differential equation.
 - Find the output of the system with $I_o = 0$ and $I_o = 1$

DIFFERENTIAL EQUATION

$$a_0 y(t) + a_1 y'(t) + \cdots + a_N y^{(N)}(t) = b_0 x(t) + b_1 x'(t) + \cdots + b_M x^{(M)}(t)$$

$$\left. \frac{d^k y(t)}{dt^k} \right|_{t=0}$$

$$k = 0, \dots, N-1$$

- **Zero-state response**
 - The output of the system when the initial conditions are zero
 - Denoted as $y_{zs}(t)$
- **Zero-input response**
 - The output of the system when the input is zero
 - Denoted as $y_{zi}(t)$
- **The actual output of the system**

$$y(t) = y_{zs}(t) + y_{zi}(t)$$

DIFFERENTIAL EQUATION

- **Example**
 - Find the zero-state output and zero-input response of the RL circuit in the previous example.